

Additional minuet non-keyed drop bolt fitting guide

Contents

Drop bolt - Qty 1



Receiver plate - Qty 1



Fixing screws - Qty 5



Masking tape - Qty 1



Router bit - Qty 1



Additional tools required

Router, Measure, Pencil and Sandpaper

Important

These works should only be carried out by a competent person with experience in working with timber and routers. Do not commence the works until you have fully established which is the top and bottom of the door and you have identified the correct routing location.

- 1) Identify correct door, stile, and routing location. You may wish to pre-hang the doors to help identify the correct location.
- 2) Lay the door onto a flat secure surface with the required routing side facing upwards.
- 3) Measure and mark the routing location following the measurements on Diagram A. The drop bolt should be installed centrally to the door stile.
- 4) Securely attach the router bit to the router and commence the works.
- 5) Once the works have been completed, lightly rub down the area with some sanding paper and clean the area of any sawdust.
- 6) Insert the drop bolt and check the fitting.
- 7) Secure the drop bolt to the door using the fixings provided. The 2 longer screws are for the bottom fixing points and the shorter screw is for the top single fixing point.
- 8) Once the doors have been installed, make a locating hole in the floor using the receiver plate as a template, then secure the receiver plate to the floor using the fixings provided.

Diagram A

